




# **Guide: Traceability in Chemical Measurements**



# Overview


- **Why traceability is important**
- **Principles of Traceability**
- **Application of these principles to chemical measurements**
- **Establishing Traceability**

# Traceability

- **“Property of the result of a measurement or the value of a standard whereby it can be related to stated references, usually national or international standards through an unbroken chain of comparisons all having stated uncertainties” (VIM 1993)**

# Views of Traceability in Chemical Measurement

**A broken chain**



**A Ball and Chain**



# Traceability

- **Traceability is a fundamental property of a result**
- **Not an optional extra**
- **Not just an additional accreditation burden**
- **It enables results to be compared**




# Principles Of Measurement

- **Value of the result is obtained from a comparison with the value of a standard  
e.g. measurement of mass**
- **Value of the result is traceable to the value of the standard**
- **Uncertainty on the result is the uncertainty on this comparison plus the uncertainty on the standard**



# Principles Of Measurement



# Principles Of Traceability

## Louisiana Cake Recipe





# BETTY RINAUDO'S RUM CAKE

**1/2 cup chopped pecans**  
**1/2 cup water**  
**1 box yellow butter cake mix**  
**1 /2 cup light rum**  
**1 small box instant vanilla**  
**pudding**  
**4 eggs**  
**1/2 cup oil**  
**1 stick butter**  
**1 cup sugar**  
**1 tbsp. rum**  
**1 tbsp. water**



# BETTY RINAUDO'S RUM CAKE

**1/2 cup (75g) chopped pecans**  
**1/2 cup (125ml) water**  
**1(250g) box yellow butter**  
**cake mix**  
**1 /2 cup (125ml) light rum**  
**1 (75g) small box instant**  
**vanilla pudding**  
**4 eggs**  
**1/2 cup (125ml) oil**  
**1 stick (150g) butter**  
**1 cup (175g) sugar**  
**1 tbsp.(15ml) rum**  
**1 tbsp.(15ml) water**



# BETTY RINAUDO'S RUM CAKE

**Prepare a 20 oz. bundt pan and sprinkle nuts in bottom.**

**Combine 1 /2 cup water, cake mix, 1 /2 cup rum, pudding mix, eggs and oil. Mix two to three minutes.**

**Pour batter into pan and bake at 350 degrees for 50 to 60 minutes.**

**For glaze, mix 1 stick butter, sugar, 1 tbsp. rum and 1 tbsp. water, then boil about 2 minutes.**


**Pour most of glaze over hot cake and let stand in pan for 30 minutes.**

**Remove cake from pan and pour remaining glaze over top of cake.**



# Principles of Traceability

A




$x_1$



Result  $y_1$

$$y_1 = f_1(x_1)$$

B



$x_2$




Result  $y_2$

$$y_2 = f_2(x_2)$$


Relationship between  $y_1$  and  $y_2$ ?

# Principles of Traceability



# Application to chemical measurements

- **Method development establishes an optimised procedure – Recipe!**
- **Validation demonstrates that this procedure is sufficiently complete for the purpose in hand**
- **Traceability or control has to be established for each parameter specified in the procedure**
- **Traceability is established by calibration using an appropriate measurement standards.**



# Application to chemical measurements

A measurement result arises from an equation

$$y = f(x_1, x_2 \dots x_m) \Big|_{x_{m+1}, x_{m+2} \dots x_n}$$

- which is assumed to hold, under certain conditions
- value of  $y$  is traceable to  $x_1, x_2, \dots x_n$

**Thus, if**

$$y = f(x_1, x_2 \dots x_m) \Big|_{x_{m+1}, x_{m+2} \dots x_n}$$

- **The sole requirement for  $y$  to be fully traceable\* is that  $x_1 \dots x_n$  are traceable or defined values**
- **Calibration for  $x_1 \dots x_n$  is sufficient**

*\*other than MU requirements*



# Establishing Traceability

- Specifying the measurand and the acceptable uncertainty
- Choosing a suitable method of estimating the value - that is, a measurement procedure with associated calculation - an equation - and measurement conditions
- Demonstrating, through validation, that the calculation and measurement conditions include all the “influence quantities” that significantly affect the result, or the value assigned to a standard.
- Identifying the relative importance of each influence quantity
- Choosing and applying appropriate reference standards
- Estimating the uncertainty

# Choosing reference standards - calibration

- Physical calibrations are well established
- Chemical calibrations can be established in the same way
  - pure CRM or matrix calibrant
- OR* (for example)
  - using a well-characterised pure material
- Uncertainty must be appropriate

# Conclusions

**How does this fit in with the definition?**

## Traceability

- **“Property of the result of a measurement or the value of a standard whereby it can be related to stated references, usually national or international standards through an unbroken chain of comparisons all having stated uncertainties” (VIM 1993)**

# Conclusions

- **Method development establishes an optimised procedure – Recipe!**
- **Validation demonstrates that this procedure is sufficiently complete for the purpose in hand**
- **Traceability or control has to be established for each parameter specified in the procedure**
- **Traceability is established by calibration using an appropriate measurement standards.**
- **These standards are traceable to higher level standards. Thus the result is traceable to the values of these higher level standards**



# Uncertainty

Live **with** uncertainty

not

**in** uncertainty

# **Application to chemical measurements**

## **Assumptions**

- **An effective quality system is in place**
  - **Trained Staff**
  - **Relevant analytical QC and QA in place**
  - **Documented methods**
- **Except for**
  - **Technical elements of traceability**

# Conclusions

If validation has shown that

$$y = f(x_1, x_2 \dots x_m) \quad \begin{array}{c} x_{m+1}, x_{m+2} \dots x_n \\ | \end{array}$$

- Then the value of  $y$ , the result, is traceable to the values of  $x_1 \dots x_n$
- The values of  $x_1 \dots x_n$  are traceable to the values of the standards used in calibration
- Thus the result is traceable to the values of these standards, which in turn are traceable to higher level standards

# **Specifying the measurand**

- **Identity of the analyte**
- **Implied measurement conditions**
- **Recovery correction**
- **Specification in terms of a method**



# Choosing a suitable method

If we assume

$$y = f(x_1, x_2 \dots x_m) \Big|_{x_{m+1}, x_{m+2} \dots x_n}$$

- The assumption(s) involved must be tested and shown to hold
- This is an essential part of method validation
- Validation is crucial to establishing traceability

# Validation

- **Unbiased**
  - Test with relevant independent CRM, spiking, intercomparisons, .....
- **Linear (test *via* linearity checks)**
- **Complete - No other effects**
  - Robustness/ruggedness; Interlaboratory studies ...

# **Estimating the uncertainty**

- **Necessary for the result**
- **Covered in uncertainty Guide**
- **The uncertainties from the measurement procedure and on the values of the standards must be included**